





### 1. Product Overview



- 1 Control Panel
- 2 Handle
- 3 Front Infrared Sensor
- 4 Filter Basket
- 5 Side Infrared Sensor
- 6 Water Sensor
- 7 Brush
- 8 Water Outlet
- 9 Charging Port
- 10 Suction Port
- 11 Scraper
- 12 Track
- 13 Power Switch


### 2. Control Panel



Control Panel	Meaning	Operation
On/Off	Wake/Sleep • Confirm	Hold 3 s to Power On/Off; Tap to Confirm
Time	1 h / 1.5 h / 2 h / Max Run	1/2/3 LEDs or Off = Select Cycle Length
Turbo	High-Power Boost	LED On = Turbo; Off = Standard
Mode	Floor Only / Floor+Wall+Waterline	Single/Double LED = Switch Cleaning Mode
AI Timer	24 h / 48 h / 72 h / Off	LED Count = Scheduled Clean Interval
Error	E1-E6 Fault Codes	See Troubleshooting
Battery	20-100 % / < 20 %	Green/Red LED = Charge Level


### 3. Power On & Charge

**Power On**  
Flip the bottom switch to **ON**.



## Charge


1. Open the charging port cover.




2. Plug in the supplied charger to 100–240 VAC.

(The plug for the Australian market is Type I - 3 pins)

3. Three green LEDs solid = fully charged.




4. Disconnect and close the cover.




## 4. App Pairing

1. Enable Bluetooth & 2.4 GHz Wi-Fi on your phone. 5G Wi-Fi is not supported.

2. Hold <  : > for 3 s until you hear a beep and the LED flashes.


3. Launch the iGarden Robotics app → Add Device → Follow prompts.

4. Set cycle, mode, turbo & schedule right from the app.



## 5. Deploy & Start


1. Go: Hold ON/OFF for 3 s. LEDs flash—set options—tap again to start.



Note: Control panel on—no ON/OFF hold.  
Only hold ON/OFF if control panel is off.

2. Place the cleaner in water within 3 minutes of power-on.

3. Gently rotate to release trapped air.



## Warnings

- Do not swim during operation.
- Charge only with the supplied adapter & battery.
- Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

## Support

✉ support@igarden.ai  
🌐 www.igarden.ai

☎ Toll-free(US): (+1)888-880-3320  
☎ Toll-free(AU): (+61)1800-716-885

See the full guide inside the box for detailed instructions.

